

Installing EZ-RJ45 Tips on Cat5e Cable

1. Cut back the outer jacket of the Cat5e cable to expose the four twisted wire pairs (shown in image on the right)
2. Untwist and straighten out the 8 twisted wires
3. Arrange the 8 wires side-by-side (from left to right) in the exact color-coded sequence shown in image below
4. With the **Tip**'s trigger facing down, push the 8 arranged wires into the **Tip** and out other end (shown below)
5. Inspect that the left-to-right sequence of the 8 wires is exactly as shown below (**very** important)
6. Holding the **Tip**, pull on the 8 wires so that the outer cable jacket is pulled tightly up into the **Tip**.
7. Insert the **Tip** into the **EZ-RJ45 Crimping Tool**, and firmly squeeze the **Tool**'s handles to permanently attach the **Tip**. This will also trim off the extra wires.

Note: Use same procedure on Cat6 cable but use EZ-RJ45 Cat6 tips

